

PRODUKTUNTERLAGEN

Doppelter wasserloser Aroma-Vernebler mit USB-C

Artikel: AATOM-37

Bedienungsanleitung

Im Anhang findest du die vom Lieferanten für diesen Artikel bereitgestellte Bedienungsanleitung in englischer Sprache. Die nachstehenden deutschen Hinweise fassen ausgewählte Angaben zusammen und ersetzen nicht die vollständige Anleitung. Beachte auch das Typenschild und die dem Gerät beiliegende Anleitung.

Dieses Modell arbeitet ohne Wasser mit 10-ml-Flaschen ätherischen Öls. Ladeanschluss: USB-Typ-C, DC 5 V / 1 A.

Nach Einsetzen der Ölfaschen nicht umdrehen oder kippen. Außerhalb der Reichweite von Kindern und Haustieren aufstellen.

Nicht zerlegen oder verändern. Laut Anleitung bei Raumtemperaturen von 10 bis 50 °C verwenden. Vor längerer Nichtbenutzung die Ölfaschen herausnehmen und sicher aufbewahren.

Die Neigungssicherung ersetzt keine aufrechte Aufstellung. Bei einer Neigung über 45 Grad stoppt das Gerät laut Anleitung; nach dem Aufrichten kann es erneut anlaufen.

Die Originaldokumente folgen vollständig und unverändert. Aussteller, Hersteller- und Kontaktangaben sind im jeweiligen Original wiedergegeben. Scent Society tritt durch die Gestaltung dieser Zusammenstellung nicht als Hersteller auf.

Fehlende aktuelle deutsche Kennzeichnungsunterlagen sowie die vollständige produktbezogene Herstellerzuordnung wurden beim Lieferanten zur Bestätigung angefragt.

Scent Society ist ein Angebot von ForgeLab:45. Fragen zu diesem Artikel: info@scent-society.de.

PRODUCT DESCRIPTION

Thank you for purchasing our dual-nozzle vehicle-mounted aroma diffuser. This product uses the latest two-fluid atomization. It does not need to add water or heat, and directly atomizes the essential oil into 1-3 nanometer particles, which will not destroy the molecular structure of the essential oil and make the essential oil more fragrant.



DUAL NOZZLE CAR AROMA DIFFUSER

Manual

Model: SZ-015



CAR ESSENTIAL
OIL AROMA DIFFUSER




Nozzle
(including empty bottle)



Type-c charging cable

FEATURES



INSTRUCTIONS

1. This product is suitable for 10ml bottled essential oils.
2. For the first use, gently push the button at the bottom with your fingers (Fig A) ; Remove the empty bottle and replace it with a new bottle of essential oil (Fig B); then put the nozzle install back to the original product, (Fig C); the triangle symbols on the nozzle need to correspond to each other (Fig D).

Note: When replacing the essential oil bottle, refer to the following figure: If the essential oil is not used up during the replacement, please erect the machine. Tighten the nozzle assembly and install it in case it cannot be removed.



3. The product is charged with a 5V DC voltage, which can be charged with a USB port adapter or a car charger with a USB port ; when the product is charging, the Type-C charging light is on ,when the battery is fully charged, the charging light is always red.
4. In the power-on state, when the remaining battery capacity is less than 15%, the charging light above the Type-c will light up in red and flash 3 times in 1S. (quick flashing) indicates that it needs to be charged.

5. Product on: Charging in power-on state, and the breathing light is on when the Type-c is charging. Until fully charged, the charging light is always red.

Product off: Charging in shutdown state, the charging breathing light is on . When fully charged, press the button for 2S to shut down.

Note: In order to avoid forgetting shutdown, the product automatically shuts down after 6H by default.



Power button: spray volume control is divided into three gears

1st gear: working 15S, dormancy 165S

2nd gear: working 60S, dormancy 120S

3rd gear: working 120S, dormancy 60S

6. Long press the power button for 2S, the product will turn on, the default timing is 6H, the 15S light is on.



Short press timing: switch the timing time 6H-1H-3H-6H . (The corresponding light is on)

The machine has a memory function, and the next time it is turned on, it will use the last working mode by default



The left nozzle or the right nozzle can be switched to work, and the corresponding triangle symbol lights up blue.

Note: Long pressing of the timing button, aromatherapy button and left and right button is invalid.

PARAMETERS

Size: 69mm*120mm

Net weight: 355g

Charging voltage: DC 5V 1A

Battery capacity: 2000mAh

Note: The above data are laboratory test values, and the data will be slightly different in different use environments.

COMMON PROBLEM

1. How long does it take to fully charge the battery?

A: 2-3 hours

2. What kind of essential oils are used in the product?

A: It is recommended to use pure plant essential oils, or essential oils that are volatile, impurity-free and non-sticky

3. Why can't I see the amount of fog when the machine is working?

A: This is a normal phenomenon. The product itself has the function of automatically adjusting the atomized particles to save essential oils to the greatest extent;

b. Atomized particles are only 1~3 nanometers, which is difficult to catch with the naked eye

In order to prevent oil leakage when the machine is accidentally dumped, if the machine is tilted more than 45 degrees, the machine will automatically stop.



Slight vibration cannot automatically stop the machine. The machine has an anti-dumping function.



After the machine is overturned, the motor will be automatically turned off. When the machine is reset, it will resume work after 5 seconds.

SAFETY SPECIFICATION

1. After the product is installed with essential oil, it cannot be turned over or tilted.
2. Do not disassemble or modify this product for any reason to avoid product damage.
3. Please use in an environment with room temperature 10°C-50°C.
4. If you do not use this product for a long time, please take out the essential oil bottle and keep it properly.
5. Do not place the product within the reach of children and pets.
6. There is an anti-dumping device inside the machine. When the machine and the nozzle shake, it will make a sound. This is a normal phenomenon.
7. Using different types of essential oils, the atomization effect will be different. (It is recommended to use oily essential oils)

